


















































T-MODEL	1960 Telecaster Custom Bridge 	1968 Telecaster Pickups in series 	1968 Telecaster Thinline Neck & Bridge 	1960 Telecaster Custom Neck 	1968 Telecaster Thinline Neck 
SPANK	1960 Stratocaster Bridge 	1960 Stratocaster Middle & Bridge 	1960 Stratocaster Middle 	1960 Stratocaster Neck & Middle 	1960 Stratocaster Neck 
LESTER	1958 Les Paul Standard Bridge 	1952 Les Paul Goldtop Bridge 	1958 Les Paul Standard Neck & Bridge 	1961 Les Paul Custom Middle & Bridge 	1958 Les Paul Standard Neck 
SPECIAL	1956 Les Paul Junior Bridge 	1976 Gibson Firebird V Neck & Bridge 	1955 Les Paul Special Neck & Bridge 	1976 Gibson Firebird V Neck 	1955 Les Paul Special Neck 
R-BILLY	1959 Gretsch 6120 Bridge 	1956 Gretsch Silverjet Bridge 	1959 Gretsch 6120 Neck & Bridge 	1956 Gretsch Silverjet Neck 	1959 Gretsch 6120 Neck 
CHIME	1968 Rickenbacker 360 Bridge 	1966 Rickenbacker 360-12 Bridge 	1968 Rickenbacker 360 Neck & Bridge 	1966 Rickenbacker 360-12 Neck 	1968 Rickenbacker 360 Neck 
SEMI	1961 Gibson ES-335 Bridge 	1967 Epiphone Casino Bridge 	1961 Gibson ES-335 Neck & Bridge 	1967 Epiphone Casino Neck 	1961 Gibson ES-335 Neck 
JAZZBOX	1957 Gibson ES-175 Bridge 	1953 Gibson Super 400 Bridge 	1957 Gibson ES-175 Neck & Bridge 	1953 Gibson Super 400 Neck 	1957 Gibson ES-175 Neck 
ACOUSTIC	1957 Martin D-28 Acoustic 	1957 Martin D12-28 Acoustic 	1967 Martin O-18 Acoustic 	1966 Guild F212 Acoustic 	1995 Gibson J-200 Acoustic 
RESO	1935 Dobro Model 2 Resonator 	Coral Sitar 	1965 Danelectro 3021 Neck & Bridge 	Gibson Mastertone Banjo 	1928 National Tricone Resonator 

Vox

Left Hand
Model settings